



English (UK)	Danish
<b>Global Commands</b>	<b>Global Commands</b>
List of commands	Liste over kommandoer
<b>Navigation Commands</b>	<b>Navigation Commands</b>
Find an address	Find en adresse
Destination my work	Destination mit arbejde
Destination home	Destination mit hjem
Previous destinations	Tidligere destinationer
Favourite destinations	Foretrukne destinationer
Find Town centre	Find Bymidte
I'm hungry	Jeg er sulten
I'm thirsty	Jeg er tørstig
I need a coffee	Jeg vil have kaffe
I need fuel	Jeg skal bruge brændstof
I need a hotel	Hvor kan jeg finde et hotel?
I need to park	Hvor kan jeg parkere?
Where is the train station?	Hvor er togstationen?
Where is the airport?	Hvor er lufthavnen?
I need to go shopping?	Hvor kan jeg shoppe?
I need a hospital	Hvor er hospitalet?
I need a pharmacy	Hvor er der et apotek?
Where is the police station?	Hvor er politistationen?
Find a POI	Find et POI
Find nearest POI	Find nærmeste POI
Find <POI category>	Find <POI-kategori>
Find nearest <POI category>	Find nærmeste <POI-kategori>
<POI category> is for example: All restaurants, all filling stations, Parking, a tourist attraction, a rest stop, a cash machine , a post office, ...	<POI category> is for example: Alle restauranter, alle tankstationer, Parkering, en turistattraktion, en rasteplads, en kontantautomat, Posthus, ...
Show traffic	Vis trafik
Show all traffic	Vis al trafik
Show map	Vis kort
Show north up	Nord op
Show heading up	Pegende op
Show 3D	Vis 3D
Repeat instruction	Gentag instruktion
Reroute	Alternativ rute
Cancel route	Annuler rute
Cancel next waypoint	Annuler næste referencepunkt
Show route	Vis rute
Route summary	Rutesammendrag

English (UK)	Danish
<b>Phone Commands</b>	<b>Phone Commands</b>
Pair phone	Par telefon
Redial	Genopkald
Dial <phone number>	Vælg <telefonnummer>
Dial	Vælg
Call	Ring
Call <name>	Ring til <Navn>
Call <name> <location>	Ring til <Navn> <Sted>
Text messages	Tekstbeskeder
Listen to message	Lyt til besked
Reply to message	Svar på besked
<b>Media Commands</b>	<b>Media Commands</b>
Bluetooth audio	Bluetooth audio
USB	USB
Play <name>	Afspil <Navn>
<name> is for example: artist name, album name, track name, genre name, list name	<name> is for example: kunstner navn, album navn, titel navn, genre navn, playliste navn
Browse all artists	Gennemse alle kunstnere
Same for: all albums, all tracks, all genres, all audiobooks, all playlists	Same for: alle albummer, alle titler, alle genrer, alle lydbøger, alle playlister
Play all	Afspil alle
<b>Radio Commands</b>	<b>Radio Commands</b>
Radio	Radio
<valid frequency> FM	FM <Gyldig frekvens>
AM	AM
FM	FM
DAB	DAB
<b>Disc Commands</b>	<b>Disc Commands</b>
CD player	CD-afspiller
<b>Climate Commands</b>	<b>Climate Commands</b>
Set temperature to <15.5 – 29.5> °C	Indstil temperatur <15,5 – 29,5> °C
Max temperature	Maksimum temperatur
Min temperature	Minimum temperatur
<b>AppLink Commands</b>	<b>AppLink Commands</b>
Mobile applications	Mobilapplikationer
<App name>	<App-navn>
Close <app name>	Afslut <App-navn>
List applications	Oplist applikationer
Find applications	Find applikationer
<b>Voice Settings</b>	<b>Voice Settings</b>
Interaction mode advanced	Interaktionstilstand ekspert
Interaction mode standard	Interaktionstilstand standard
Call confirmation off	Opkaldsbekræftelse fra
Call confirmation on	Opkaldsbekræftelse til